

CLEAN X-POLYMER

Operating Procedures

Substrate Treatment Iron Powder+Water Stain Removal



① Clean mud and oil stains on tires and wheels with a tire brush and sponge.



② Remove insects with a super insect cleaner as need.



③ Hand wash or car wash machine.



④ Use 'Zara Clean' and horsehair brush to clean the dirt on small parts.



⑤ Remove Iron Powder with water or 'Zara Clean'+ 'Zeus'.



⑥ Remove water stains with CleanX-7 or White Cleaner.

Clean X-Polymer Coating



⑦ Add water to the sponge to drain it or give a proper amount of water in spray bottle. (Workability Improvement)



⑧ Apply an appropriate amount of Clean X Polymer to the sponge.



⑨ Apply liquid agent to the sponge and apply to body 50cm square.



⑩ When the coting finished, remove water on the sponge.



⑪ Drained with a sponge, trace the applied area 80% dry wipe.



⑫ The remaining liquid, wipe dry with a chemical tower or special cloth.